

Autodesk®

Autodesk® Navisworks® Freedom® 2012

Autodesk® Navisworks® Simulate® 2012

Autodesk® Navisworks® Manage® 2012

System Requirements (32-bit & 64-bit)

Operating System

- Microsoft® Windows® 7 Enterprise
- Windows 7 Ultimate
- Windows 7 Professional
- Windows 7 Home Premium
- Windows 7 Home Basic

Service Pack 2 (SP2) or later of the following

- Microsoft® Windows Vista® Enterprise
- Windows Vista Ultimate
- Windows Vista Business
- Windows Vista Home Premium

Service Pack 2 (SP2) or later of the following:

- Microsoft® Windows XP Professional x64 Edition

Service Pack 3 (SP3) or later of the following:

- Windows XP Professional (32-bit)
- Windows XP Home (32-bit)

Browser

- Windows Internet Explorer® 7.0 or later

CPU Type

- Intel Pentium 4 / AMD Athlon 3.0GHz (or higher) with SSE2 technology

Memory

- 512 MB RAM (minimum)
- 2 GB or greater RAM (recommended)

Display Resolution

- 1024x768 with True Color (minimum)
- 1280x1024 (recommended)

Display Card

- Direct3D 9 and OpenGL capable graphics card with Shader Model 2

Hard Disk

- Installation 11 GB free disk space for installation

Pointing Device

- Microsoft-Mouse compliant

Plotter/Printer

- Optional

Media

- Download or installation from DVD